

# DCS REMOTE HANDHELD LCD CODE DEFINITIONS

ACRONYM	DEFINITION
BATT	Low Battery indicator
C	ProtoCast is active
D	Doppler is active
L	Engine displayed is a Lash-Up
M	External Microphone is active
P	Playing back a previously recorded playback session
R	Recording a playback session
T	Remote is tethered to TIU
Z	Z4K track is being controlled